


Bonsai Arched Decorative Garden Bridge



Component List

4 x Newel Posts	(85mm x 85mm)	1200mm	(A)
2 x Curved Support Beam	(95mm x 44mm)	1200mm	(B)
10 x Walkway Boards	(120mm x 28mm)	900mm	(C)
2 x Curved Handrails	(95mm x 44mm)	1200mm	(D)
8 x 150mm Carriage Bolts (Inc Nut & Washer)			(FIX 1)
40 x 60mm Green Coated Screws			(FIX 2)
8 x 150mm Handrail Fixing Screws			(FIX 3)

Tools Required

Drill Driver
PZ2 Driver Bit
10mm Socket / Spanner
10mm Drill Bit
Pencil
Tape Measure
Spirit Level




A minimum of two people are required to assemble this product.

All images are for illustration only. Please see individual item listings for actual item specifications.

Page 1 of 5


Bonsai Arched Decorative Garden Bridge



Step 1

To prevent splits, drill a pilot hole before driving screws

To begin your build, first start by placing the 2 x Curved Support Beams (B) down on the ground opposite one another as per the diagram below.



Step 2

Starting at one end, fasten down the first Walkway Board (C), using 2 x 60mm Green Coated Screws (FIX 2) per side, driving through the board and into the Curved Support Beam (B) below.

The edge of the board should fit flush with the support beams underneath.


For stability when building, we would suggest then fitting the opposing end starter board in the same way.

Repeat the process all along the support beams until they are fully covered, using approx. 10mm spacing gaps in between so that the boards are spaced evenly.



All images are for illustration only. Please see individual item listings for actual item specifications.

Bonsai Arched Decorative Garden Bridge



Step 3

To prevent splits, drill a pilot hole before driving screws

With the walkway completed, you can now move on to installing the 4 x Newel Posts (A) that the Handrails (D) will be attached to later.

You will need to drill holes in the correct place, through the newel and the support beams using a 10mm drill bit.

The Newel Posts (A) are attached using 2 x 150mm Carriage Bolts (FIX 1) per post as indicated below, with the included washer attached to the rear to help the nut pull the bolt tight and secure.




The Newel Posts (A) should be positioned so that they are flush with the Curved Support Beams (B), see right for reference.



All images are for illustration only. Please see individual item listings for actual item specifications.

Bonsai Arched Decorative Garden Bridge



Step 4

To prevent splits, drill a pilot hole before driving screws

With the Newel Posts (A) fixed in place the Handrails can be attached using the screws provided.

Simply slot in between the newels and fix into place using 2 x 150mm Handrail Fixing Screws (FIX 3) per side as indicated in the diagram to the right, driving through the post and into the handrail.


The height which you choose to install the handrails is at your discretion but we recommend just below the bottom ridge on the newel post.



All images are for illustration only. Please see individual item listings for actual item specifications.

Page 4 of 5

Bonsai Arched Decorative Garden Bridge



**Enjoy your new Bonsai Arched
Decorative Garden Bridge!**

All images are for illustration only. Please see individual item listings for actual item specifications.

Page 5 of 5